
**CFS-25 Combination Foldable Studreel & Floor Reel Instruction Manual** 




# **Table of Contents**

Parts List	3
Assembly	5
Making Adjustments	12

**Parts List** 





Part Number	Part Name	Quantity
1	Spindle Rod	1
	FSR-100	
2	Hex Set-Screw Bushing	2
	FSR-101-A	
3	Wire Hub Arm	4
	FSR-102	
4	Spring	1
	FSR-103	
5	Wire Tray Arm Stop Washer	1
	FSR-104	
6	Wire Tray Arm	4
	FSR-105	
7	Star Hub	2
	FSR-106-B	
8	Small Washer	1
	FSR-108	
9	Arms Assembly Nut & Screw	12
	FSR-109	
10	Swivel Mount Assembly Weldment	1
	FSR-110	
11	Stud Mount Assembly Weldment	1
	FSR-112	
12	Wire Guide Set-Screw	1
	FSR-115	
13	Wire Guide	1
	FSR-116	
14	5/16" Bolt, Washers & Nut	1
	FSR-117	
15	5/8" Jam Nuts	2
	HDFR-111	
16	Floor Bracket Complete	1
	HDFR-114	
17	Rubber Cap	4
	HDFR-113	

#### Assembly

# **Assembly of Arms Assembly**

To assemble the wire hub and attach the wire tray arms (FSR-105), the wire hub arms (FSR-102) have to be attached to the star hub (FSR-106-B) using an arms assembly nut & screw (FSR-109) as shown in figure 1. Each wire hub arm should also be attached to one of the hub mount holes on the corresponding wire tray arm once again using an arms assembly nut & screw. Finally, the wire tray arms should be attached to a second star hub.




Figure 1 Assembly of Arms Assembly.

To finish assembling the arms assembly, the rest of the assembly has to slide onto the spindle rod (FSR-100). First, the set-screws in the hex set-screw bushings (FSR-101-A) have to be loosened so that they can slide onto the spindle rod. Next the swivel mount assembly weldment should be slid onto the bottom of the spindle rod. Then the two hex set-screw bushings, the wire tray arm stop washer (FSR-104), the spring (FSR-103), and the small washer (FSR-108) should be slid onto the spindle rod between the two star hubs as shown in figure 2.




Figure 2
The parts of the arms assembly should be stacked on the spindle rod in the order shown above.

Underneath the swivel mount assembly weldment, the wire guide (FSR-116) should be slid onto the spindle rod, seen in figure 3. To finish assembly, the set-screws in the wire guide and hex set-screw bushings should be tightened to raise the wire tray arms to the preferred angle. When this is achieved, the top het set-screw bushing should be snug with the top star hub, and the bottom bushing, stop washer, spring and small washer should securely rest on the bottom star hub. Instructions on adjusting the angle of the wire tray arms can be found on pages 12-13




Figure 3
The swivel mount assembly weldment and the spindle rod should slide on the spindle rod underneath the rest of the arms assembly.

## Dismounting the Stud Mount Assembly Weldment from the Floor Bracket

The stud mount assembly weldment will come attached to the floor bracket. In order to use the floor bracket or the stud mount, they need to be separated. In order to do this, the 5/16" bolt, washers & nut (FSR-117) need to be removed, which is shown in figure 4. The stud mount

assembly can then be detached from the floor bracket. When it is removed, make sure to screw the 5/16" bolt, washers & nut back onto the stud mount assembly weldment because it will be used later.




Figure 4 The 5/16" bolt, washers & nut need to be unscrewed and removed first in order to dismount the stud mount assembly weldment from the floor bracket.

#### Mounting the Arms Assembly to the Stud Mount Assembly Weldment

Next, the arms assembly can be attached to the stud mount assembly weldment. This is done by using the 5/16" bolt, washers & nut to fasten the swivel mount assembly weldment to the stud mount assembly weldment as seen below in figure 5.




Figure 5 The 5/16" Bolt is used to attach the stud mount assembly weldment and the swivel mount assembly weldment together.

#### Dismounting the Arms assembly from the Out-of-Box Position

Once again, the stud mount assembly weldment will come attached to the floor bracket. In order to use the floor bracket or the stud mount, they need to be separated. To do this, the bottom (farthest right in figure 6) 5/8" Jam Nut (HDFR-111) needs to be unscrewed and removed from the swivel mount assembly weldment (FSR-110) so that the arms assembly slides off. Do not forget to screw the jam nut back onto the swivel mount assembly weldment since it will be used later.




Figure 6
The arms assembly comes screwed to the floor bracket. This must be dismounted.

#### **Mounting the Arms Assembly to the Floor Bracket**

The arms assembly has to be attached to the floor bracket in order to use it as a floor reel. First screw a 5/8" jam nut (HDFR-111) onto the swivel mount assembly weldment (FSR-110). Then slide the swivel mount assembly weldment through the hole in the floor bracket as shown in figure 7. Finally, screw the second 5/8" jam nut underneath the floor bracket to pinch it in place.




Figure 7
The jam nuts need to be screwed onto the swivel mount assembly, pinching the floor bracket between the two nuts.

To maximize the mobility of the wire guide it is important to align the swivel mount assembly weldment properly. There is a bump on the floor bracket that was welded there to help you align the swivel mount. When the 5/8" jam nuts are tightened, make sure that the swivel mount assembly weldment aligns with the bump on the floor bracket as shown in figure 8.




Figure 8
The swivel mount assembly weldment needs to be aligned with the bump on the floor bracket to maximize the wire guide rotation mobility.

#### Mounting to a Stud

Now that everything is assembled, it can be mounted to a 2x4 or 2x6 stud. One side of the stud mount assembly weldment (FSR-112) has hooks for mounting a 2x6 and the opposite side is for a 2x4. Either way the procedure is the same. Tilt the stud mound assembly at about a 30° angle as seen in figure 9. Fit the hooks around the stud and rotate the stud mount so that the crossbar is level.




Figure 9 Mounting the assembly is easy. In this case the stud mount is being used for a 2x6 stud, but the two closest can be used for a 2x4.

The FSR-C Combination Foldable Studreel & Floor Reel is now fully assembled. The next section will help you if you want to make some adjustments.

## **Making Adjustments**

#### **Raising or Lowering the Wire Tray Arms**

To raise or lower the wire tray arms (FSR-105) the user must first unscrew the set screw in the screw bushing (FSR-101-A) labelled in figure 1 until loose. Then the screw bushing can slide up or down the spindle rod (FSR-100) to the satisfactory height, and the set-screw can be tightened again to hold the wire tray arms in the desired position. This process can be seen in figure 10 below.



Figure 10 Screw bushing is slid up the spindle rod to raise the wire tray arms, or slid down to lower the arms.

# **Adjusting Wire Tray Hub Diameter**

Sometimes it is necessary to adjust the diameter of the wire tray hub diameter to accommodate a different sized spool or wire. To do this, the arms assembly nuts & screws (FSR-109) that connect the wire try arms (FSR-105) to the wire hub arms (FSR-102) must be unscrewed and removed. The wire hub arms can then be attached to the wire tray arms using an alternative mounting hole at the base of the wire tray arms. This process is illustrated in figure 11 below.




Figure 11 Wire hub arms can be reattached at an alternate mounting hole in the wire tray arms to accommodate different spool.

Note: only the two holes in the wire tray arms shown in figure 12 are meant to be used to mount to the wire hub arms.




Figure 12 Mounting holes in wire tray arm form wire hub arm